

First Responder:

POWERED AIR PURIFYING RESPIRATORS

CDC-recommended PPE

| Trained | Observer: _ | | Date: | 1. 2. 6 | |
|--|--|---|---|---|--|
| PURPOSE: This checklist has been developed to assi Personal Protective Equipment (PPE), and securing or | | | ist First Responders in the proper donning and doffing of n-scene used PPE. | + + { | OR 🧪 |
| HOW TO The CDC CDC for A (www man. CDC Virus (www IMPORT | D USE: This coinstructional Fit training videos Interim Guidar Management of w.cdc.gov/whf/eb. Guidance on Per Disease in U.S. w.cdc.gov/whf/eb. TANT NOTES: hing and doffing and doffing and doffing instruction. | Incument should be used by Trast Responder Ebola Briefing + PPE F for donning and doffing PPE (www.co for Emergency Medical Services (Patients with Known or Suspected Ebola/hcp/interim-guidance-emergency ts-known-suspected-united-states.htm for Suspected Ebola/hcp/interim-guidance-emergency for Hospitals, Including Procedures for Fola/hcp/procedures-for-ppe.html). | ined Observers and First Responders in conjunction with: owerPoint published November 13, 2014. ic.gov/htf/ebola/hcp/ppe-training/). EMS) Systems and 9-1-1 Public Safety Answering Points (PSAPs) ola Virus Disease in the United States – October 28, 2014. medical-services-systems-911-public-safety-answering-points- ni). ed by Healthcare Workers During Management of Patients with Ebola lutting On (Donning) and Removing (Doffing) – October 20, 2014. | TWO PAIRS OF SINGLE-USE (INTERPRETATION AND SINGLE-USE) (INTERPRETATION AND BOOT OF SINGLE-USE (BISPOSABLE) HOUTE (AND APPROX AND BOOT OF SINGLE-USE (BISPOSABLE) HOUTE (BISPOSABLE) (BISPOSABLE) (BISPOSABLE) (BISPOSABLE) HOUTE (BISPOSABLE) | COVERALIS HAVE S) esistant or impermeab session or impermeab DD (IP PAPR IS REUSABLE) ACE SHIELD |
| Prior to donning, designate a Work Zone for doffing. Work Zone should allow a clear separation between clean and potentially contaminated areas and should be located as close to the Hot Zone as safely feasible . | | | | | |
| | Step 1. | Engage Trained Observer | Using a written checklist and verbal commands, the donning process is conducted under the guidance and supervision of a Trained Observer. □ Trained Observer confirms visually and documents that all PPE is serviceable and has been donned successfully, ensuring and verifying the integrity of the ensemble. □ OUTCOME: NO exposed skin or hair should be visible at the conclusion of the donning process. | | |
| | Step 2. | Remove Personal Clothing and Items | ☐ In a clean area, change into surgical scrubs (or disposable garments) and dedicated washable (plastic or rubber) footwear with closed toe and heels, and no holes. ☐ Remove personal items (e.g., jewelry, watches, cell phones, pagers, pens). | | |
| | Step 3. | Inspect PPE Prior to Donning | Visually inspect: PPE ensemble to ensure it is in serviceable condition. All required PPE and supplies are available. Trained Observer reviews the donning sequenc in a step-by-step fashion. | Sizes selected are correct. be before beginning the donning process, reading | g aloud |
| | Step 4. | Perform Hand Hygiene | Perform hand hygiene with alcohol-based hand | rub (ABHR). Allow hands to dry before next step. | |
| | Step 5. | Put on Inner Gloves | Put on first pair of gloves . Cuffs should extend as far up the arms as possible. | | |
| | Step 6. | Put on Boot or Shoe Covers | Boot covers should extend to mid-calf. Shoe covers are acceptable ONLY if used with a coverall with integrated socks. | | |
| | Step 7. | Put on Coverall | □ Ensure coverall: □ Is large enough for unrestricted freedom of movement. □ Cuffs of inner gloves are tucked under the sleeve of the coverall. □ If tape is needed to secure sleeves over inner gloves, use buddy tabs to facilitate later removal. □ If PAPR with a self-contained filter and blower unit integrated inside the helmet is used, belt and battery unit MUST be put on prior to donning coverall so that belt/battery unit are under the coverall. □ If PAPR with external belt-mounted blower is used, blower and tubing MUST be outside of the coverall to ensure proper airflow. | | |
| | Step 8. | Put on Outer Gloves | Put on second pair of gloves (with extended cuffs). Ensure cuffs are pulled over coverall sleeves, extending as far up arms as possible. — Using different color gloves when double gloving makes it easier to see contamination, cuts or tears. | | |
| | Step 9. | Put on Respirator | Put on PAPR. It should have a full face-shield , helmet or headpiece . — If either a PAPR with a self-contained filter and blower unit integrated inside the helmet is used, – OR a PAPR with external belt-mounted blower unit and attached reusable headpiece is used – a single-use (disposable) hood MUST also be used. — Hood MUST fully cover all hair , neck and ears and extend past the neck to the shoulders . | | |
| | Step 10. | Put on Outer Apron (if used) | Put on full-body outer apron to provide additional protection to the front of the body. Apron should extend to mid-calf . | | |
| | Step 11. | Verify | Trained Observer verifies: Donning process is complete and the integrity of the ensemble. First Responder is comfortable and able to extend arms, bend at the waist, and go through a range of motions to ensure sufficient range of movement while all areas of the body remain covered. | | |
| | Step 12. | Disinfect Outer Gloves | Disinfect outer-gloved hands with ABHR. Allow | to dry prior to patient contact. | |